

COMPLETED OVEN STYLES WITH STANDS

**CANNON
OVEN PACKAGE**

38" model shown



**COLONIAL
OVEN PACKAGE**

38" model shown

**FRONTIER
OVEN PACKAGE**

38" model shown

OVEN SIZES AND DIMENSIONS



SMALL – FP1 DIMENSIONS

INSIDE DIMENSIONS	19" wide x 24" deep x 15.25" high
OUTSIDE DIMENSIONS (BOX)	30" wide x 29.5" deep
OUTSIDE DIMENSIONS (CAP)	32.75" wide x 33" deep
OVERALL HEIGHT	48"
HEARTH OPENING	11.5" wide x 14.5" arch height

MEDIUM – FP2 DIMENSIONS

INSIDE DIMENSIONS	21" wide x 29" deep x 13" high
OUTSIDE DIMENSIONS (BOX)	36" wide x 39" deep
OUTSIDE DIMENSIONS (CAP)	38.5" wide x 41.5" deep
OVERALL HEIGHT	60"
HEARTH OPENING	19.5" wide x 9" arch height

LARGE – FP3 DIMENSIONS

INSIDE DIMENSIONS	30" wide x 39" deep x 13" high
OUTSIDE DIMENSIONS (BOX)	48" wide x 49" deep
OUTSIDE DIMENSIONS (CAP)	48" wide x 49" deep
OVERALL HEIGHT	78"
HEARTH OPENING (Small)	20.75" wide x 9" arch height
HEARTH OPENING (Large)	27.5" wide x 10" arch height

CUSTOMIZE YOUR OVEN

STEP 1:



Choose your oven size and style

STEP 2:



Choose your oven base and material

STEP 3:



Select accessories and you're finished!

